

QE2

Set time and day

- 1/ push slider over to SET TIME AND DAY
- 2/ Push DAY, HOUR & MINUTE to set current time and day

Programming your QE2

- 1/ push slider over to SET OWN PROGRAMME
- 2/ Display will show ON and blanks were time should be
- 3/ Input the amount of days by repeatedly pushing the DAY button
- 4/ Push the HOUR & MINUTE button to select your on time
- 5/ Push the COPY button to save
- 6/ Now the display will show OFF
- 7/ Repeat steps 3,4,5,
- 8/ Once all programmes are entered push slider to run own program

Note: If you require different times for CENTRAL HEATING and DOMESTIC HOT WATER, press the CENTRAL HEATING or DOMESTIC HOT WATER button instead of the copy button when programming. SEE 5.